

USER MANUAL

IntelliStitch®

Equalizer User Manual

written by

Helen Baczynski

Zoltan Kasa

Copyright © 2006, Kasa Engineering Services

www.intellistitch.com

INDEX

FEATURES OF THE EQUALIZER

OVERVIEW	2
CONTROL PANELS	3
START/STOP BUTTON	3
NEEDLE POSITION BUTTON	3

MODES OF OPERATION

REGULATED STITCHING MODE	4
CONSTANT SPEED MODE	5
NEEDLE JAM DETECTION	5
ADJUSTMENT MODE	5

QUICK GUIDE TO THE BEEP AND LIGHT SIGNALS	6
--------------------------------------------------	----------

QUILTING WITH THE EQUALIZER

DAILY MAINTENANCE AND WARM UP	7
--------------------------------------	----------

PRACTICE LESSONS

Lesson 1. Getting to know all the features.	8
Lesson 2. Using regulated stitching - minimum effort method.	11
Lesson 3. Using regulated stitching - more practicing	13
Lesson 4. Using constant speed.	15
Lesson 5. Comparing regulated stitching to constant speed.	16

HELP!	19
--------------	-----------

ADJUSTMENT PROCEDURE	21
-----------------------------	-----------

FEATURES OF THE EQUALIZER

OVERVIEW

The Equalizer is a motor controller installed on your quilting machine. It consists of a computer unit mounted on the top of your machine, with front and back control panels, handle switches, two track sensor wheels and a needle position sensor.

The controller is driven by software embedded inside a microchip. Upgrades of the software are done by replacing the old program chip with one containing the new version.

The track sensors measure the changing position of the needle as the machine is moved. The needle position sensor recognizes if the needle is up or down. The stitching mode and other commands are set on the control panels. The controller uses all this data to determine when a stitch should be completed and then sends a command to the motor.

The controller moves the needle in and out of the fabric within the shortest distance of machine movement, minimizing needle flexing. This speed sensitive operation makes the stitching smooth when the machine is moved slowly, but allows for more powerful, higher speed stitches when the machine is moved faster. The controller will always tell the machine to make a stitch at the point of a sharp turn, even if that position does not fall on a selected stitch length. This gives a sharp looking point every time.

All functions, except turning on the power, can be controlled by either the front or back control panels. As a safety feature, the automatic lockout keeps track of which control panel is being used each time. This prevents someone on one side of the machine from inadvertently switching functions when you are operating the machine from the other side.

Two copies of the setup data (motor speed and needle positions) are stored in the memory of the controller. This memory retains the data even if the power is turned off. Every time the machine is turned on a data validity test is performed and the machine goes into normal operation.

If the data in one block is detected as being corrupted, the other block will be used. If the data in that block is corrupted, the FAIL light flashes and the machine beeps four times, and the factory default settings will be restored. This happens very rarely but if it should, then the adjustment procedure should be followed.

CONTROL PANELS

All the controls are active on both sides of the machine. You can turn the regulator on/off, set stitch length or speed, position the needle from both sides. However, when the black start/stop button is pushed on one side, the controls on the other side will be disabled, with the exception of the black start/stop button that acts as an emergency stop.

The type of stitching is determined by how the sliding switch is set on the side where the start/stop button is pushed. It is important to always glance at the control panel before you start sewing to make sure it is set correctly. This is especially important if you move from one side of the machine to the other.

The yellow "ON" light indicates when the main power to the machine is on.



The green "RUN" light indicates that the machine is armed and ready to sew. The light flashes when the machine has not been moved for 4 seconds.

The slider in the middle is used to set the stitch length, when the switch is up, or the constant speed, when the switch is down.

The red "FAIL" light serves as a warning light. If it flashes when you are using regulated stitching mode, it is indicating that the stitches have reached twice the chosen length and you are moving the machine too fast. It will be continuously lit when the controller detects a needle jam.

The mode switch on the right is where you choose which stitching mode you want to use. Slide the switch up to select the regulated mode, down to select the constant speed mode.

START/STOP BUTTON

This is the black button on the right handle. It needs to be held down for about a sixteenth of a second to either start or stop the machine. The machine is protected from accidental starts triggered by a noise spike on the power line or an accidental hit of the start/stop button.

NEEDLE POSITIONING BUTTON

This is the red button on the left handle, which toggles between needle up and needle down positions. The needle will return to the position that was set before starting stitching when the stitching is stopped with the black start/stop switch. If the needle is at the down position when the start switch is pressed, it will be pulled up before the stitching starts. NOTE that you should wait without moving the arm until the pull-up is complete to avoid needle flexing and breakage.

MODES OF OPERATION

REGULATED STITCHING MODE

The regulated stitching mode is selected when the mode switch is in the "up" position at the moment when the black start/stop button is pushed.

Although the slider is continuous, there are only eight discreet settings in the regulated stitching mode. The line on the knob should be aligned with the middle of the bars above the slider. The bars represent stitch lengths from about 6 SPI (tallest bar) to close to 16 SPI (shortest bar).

In regulated stitching mode the motor will not start when you press the start/stop button, only the green run light will come on indicating that the machine is "armed". The motor will start when you move the machine and will continue to stitch, according to the preset stitch length, until you stop moving the machine or you press the start/stop button.

If you pause while stitching and do not press the start/stop button, the needle will be pulled up and the machine will stay armed for about 8 seconds. The motor will start when the machine is moved again. If you pause for the full 8 seconds, the green run light will begin to flash after 4 seconds and the machine will disarm itself after 4 more seconds. This is a safety feature. The flashing light will catch your eye and remind you that the machine is armed and will start to sew if it is jogged by accident. You should keep your fingers away from the needle when the machine is still armed but not moving. When the machine disarms itself, it will sound one beep.

If you choose to start with your needle down, then the machine will lift the needle out of the fabric when you press the start button and the green run light will come on. You should wait for the needle to be lifted before you start to move the machine. The needle will stay up if you pause while you are quilting. It will only return to the chosen down position when you press the stop button or when the machine disarms itself.

The stitch regulator keeps the stitches at the selected length no matter how fast or how slowly you move the machine. However, there is a speed limit and if you move the machine faster than that limit you will get longer stitches. During your initial practice following the lessons, you will find out when you reach this speed limit. Some quilters move very quickly when doing freehand or pantograph quilting and therefore should not use the regulated stitching for that type of work.

Every time a stitch gets longer than twice the selected length, the red FAIL light will be turned on and a beep will sound. This long stitch indication is turned on not only when you move the machine too fast, but when there is a sudden speed change, usually at corners or points in a pattern or when you first start off. You may find that you get some long stitches at first because you are used to moving quickly through points and at start off in order to prevent a build up of stitches.

We recommend that you move the machine with a more natural motion using minimum effort. You will not have to force your machine to quickly change direction anymore, you will be able to simply guide it.

CONSTANT SPEED MODE

The constant speed mode is selected when the mode switch is set to the "down" position when the black start/stop button is pushed.

When you press the start/stop button the machine will begin sewing immediately. However, if you choose needle down the machine will lift the needle out of the fabric before starting to sew. You need to wait for this needle pull up to be completed before moving the machine.

When the slider is set at the left, the machine will run in a pulsed mode. This is the no-drag slow speed feature, exclusive to IntelliStitch-brand controllers. It eliminates needle flexing and fabric stretching which happens at extremely slow constant speed. At the leftmost slider position the machine will take one stitch per second regardless of how fast or how slowly you move your machine. Moving the slider to the right will increase the number of stitches per second, up to 10 stitches per second. Above 10, the motor runs continuously, with variable speed, determined by the slider position.

NEEDLE JAM DETECTION

If there is any obstruction that prevents the needle from moving or making a complete stitch, a slightly more powerful pulse will be applied by the motor to move the needle. If, however, the motor cannot move the needle, the red fail light will come on, a continuous beep will sound and the motor will be turned off.

This can happen at very thick seams. If you know a thick seam is causing the jam signal to sound, then all you need to do is turn the handwheel by hand to raise the needle, move the machine very slightly and start to quilt again by pressing the start/stop button.

If the needle jam signal goes off for no apparent reason, you need to turn off the main power to the machine, raise the needle by turning the handwheel and move the machine away from your work to find the cause of the jam before continuing.

ADJUSTMENT MODE

You should not need to use this, but in the event that your machine loses both its main memory and its back up memory, you will need to re-set it by running the auto-adjustment.

To get into adjustment mode, hold down the red needle position button while powering up. Adjustment can only be done at the back of the machine. The light above the laser button will flash continuously to indicate that you are in adjustment mode.

Adjustment details and instructions can be found at the end of this guide.

QUICK GUIDE TO THE BEEP AND LIGHT SIGNALS

AT POWER UP

ONE BEEP - the regulator is ready for operation. The beep will be followed by a needle positioning cycle. NOTE: if the motor starts running BEFORE the beep sounds, it indicates system malfunction. When this happens, turn off the machine and call service.

FOUR BEEPS - the set-up memory has been lost or corrupted and the factory default settings have been restored. The machine has gone into set up mode so that you can re-set it.

REPEATED BEEPS - one of the switches is shorted. Turn off the machine and call service.

CONTINUOUS BEEP WITH FAIL LIGHT - system malfunction. Turn off the machine and call service.

RUN LIGHT FLASHING – you are in adjustment mode.

WHEN QUILTING

CONTINUOUS BEEP WITH FAIL LIGHT – a jam has been detected.

BEEP AND ONE FLASH OF THE FAIL LIGHT WHILE QUILTING IN REGULATED STITCHING MODE – a long stitch has been detected

ONE BEEP AFTER THE MACHINE HAS NOT MOVED FOR 8 SECONDS WHEN ARMED– the machine has just disarmed itself

QUILTING WITH THE EQUALIZER

This section will not give you definitive instructions on how you should use the different modes of operation of your Equalizer. There is no one correct way – each quilter will use the features differently to suit their style. To help you decide how you will use the Equalizer, follow the series of lessons after the daily maintenance section.

The daily maintenance and warm up are important and you should follow these instructions each day before you begin to quilt.

DAILY MAINTENANCE AND WARM UP

BEFORE POWER UP

Touch your table to discharge any static.

Move the machine away from any work you have mounted.

Check the cleanliness of the sensor wheels and the rails. Wipe the rails with rubbing alcohol if necessary and clean the wheels with a cloth. It is important to keep the wheels and rails free of oil and lint so that they can relay the correct information to the controller. Check that there is no thread caught around the sensor wheel shafts.

Remove the bobbin and the bobbin case. Unthread the machine to before the take up lever.

Put one or two drops of oil in the bobbin area and at all the oiling points.

POWER UP

When the power is turned on with the main power switch on the top of the machine, the machine will always take one or more stitches. This is necessary for the needle position sensor to find its "home" position. Before turning on the power check that there is nothing in the way of the needle.

While the machine is powering up, sounds and lights give important information. See the Quick Guide to the Beep and Light Signals page for an explanation.

WARM UP

Before you start a quilting session, it is important to warm up the machine so that it can react promptly to the signals it receives.

Before running the warm up cycle, make sure you have removed your bobbin case and have unthreaded the top thread to before your take up lever. Do not leave the take up lever threaded as its movement can cause the thread to be sucked inside the machine, where it will start to wind around the shaft beside the handwheel. Since the thread will eventually break, you may be unaware of the build up inside the machine but it can cause your machine to bind, stitch erratically and make the motor overheat.

To warm up the machine, select constant speed with the mode switch, set the slider to a medium speed and start the machine. Leave the machine running for about 5 minutes.

PRACTICE LESSONS

This is a series of lessons to help you familiarize yourself with your Equalizer. The lessons begin by being very detailed in their instructions. As you progress, the instructions become less detailed as it is assumed that do not need to be reminded when or how to tie off your threads or advance and baste the sides of your practice piece. Most of the work is done at the front, or needle side, of the machine. You can repeat the sewing exercises as necessary.

These lessons will give you a good start in using the Equalizer. How you eventually use the different operating modes is a decision only you can make. Some quilters use the Regulated Stitching mode all the time, others prefer to use Constant Speed for certain things. There is no right or wrong way to use the features of the Equalizer. You should use them to suit your style of quilting.

Follow the page of daily maintenance instructions before starting these lessons.

LESSON 1. GETTING TO KNOW THE FEATURES OF THE EQUALIZER. FINDING OUT WHAT ALL THE BUTTONS DO AND WHAT THE LIGHTS, BEEPS AND NUMBERS MEAN.

Mount a practice piece of plain fabric and thread your machine with a contrasting color of thread so that your sewing can be seen clearly. Read each paragraph through before following the instructions.

Move your machine to the side of your table away from the practice piece and make sure the needle is away from the clamps.

Turn off the main power to your machine. Now turn it on again. It will take one stitch and some beeps will sound and perhaps some lights will flash. What did you hear and see? Do you know what they mean? If not, refer to the Quick Guide to the Beep and Light Signals page.

Every time you power up, the machine will take one or more stitches. This is simply a self-checking routine.

Go to the needle side or front of your machine. Move the machine over your practice piece. Bring the bobbin thread to the top by using the needle position button. Where is the needle position button? Read the page with the picture of the control panel if you have forgotten. Hold both thread ends and use the needle position button to take multiple stitches very close together or on top of one another to secure the ends.

Set your mode switch to the "up" position and the slider to the leftmost bar – what does this mean? Refer back to the section about the Regulated Stitching Mode.

Press the start/stop button. Look at the control panel and watch for the green RUN light to come on – when you see it, release the button. The machine is now armed and ready to sew but it will not begin until you move the machine. Sew a line of stitches quite slowly. Stop moving the machine, then press the black start/stop button to disarm the machine. Watch for the green RUN light to go out. Now use the needle position button to do repeated stitches to tie off the threads.

Again, bring the bobbin thread up and take multiple stitches to secure the ends.

Watch for the green RUN light as you press the start/stop button. When you see it come on, you can release the button. What is the light telling you?

Sew a line of stitches – do not move the machine fast. Stop moving the machine after about 10 stitches but do not press the start/stop button. The green RUN light is still on so what will happen if you move the machine or even accidentally jog it? Do not move the machine – watch the green light. What happens after 4 seconds? Why? What happens after 4 more seconds?

The fast flashing of the light reminds you that the machine is still armed and ready to sew, so keep your fingers away from the needle. The machine will always disarm itself after 8 seconds of non-movement.

Move the slider to the next bar – what does this mean? Arm the machine – watch for the green RUN light to come on. Move the machine and sew. After a few inches, pause (stop moving the machine) and move the slider to the next bar. Move the machine again. What do you notice about the stitches? Why did they change? Sew a little then pause and disarm the machine.

Move your slider to the shortest bar. Arm the machine and start to sew. Gradually move the machine faster and faster and watch the FAIL light until you see it flash and hear a beep at the same time. Sometimes it is hard to hear the beep. Pause then disarm the machine. Look at your stitches – what was the fail light telling you? Refer back to the Regulated Stitching Mode section to find out.

Now you're going to sew in constant speed. What is constant speed? You'd press the button and the motor would run at a constant speed.

How to select the constant speed mode? Forgotten? Refer back to the picture of the control panel.

Set your mode switch to the "down" position and move the slider to the middle. Bring your bobbin thread up and secure the ends just as you've done before. Now get ready – as soon as you arm the machine, it will begin to sew whether it is moving or not. Arm the machine (press the start/stop button) and move your machine straight away. If you want to go faster, move the slider to the right. If you want to slow down, move it to the left. You can do this while the machine is running. Disarm the machine when you are ready.

Set the slider all the way to the left. At this position the machine will sew one stitch per second regardless of how fast or how slowly you move it. This is called no-drag slow speed. Read the Constant Speed section for an explanation.

Disarm the machine. Set the mode switch to the "up" position and move the slider to the fourth bar. Press the needle position button. What happened? Press it again – what happened?

This button selects needle down or up. Put the needle down again. Now arm the machine – remember, watch for the green RUN light to come on. Don't move the machine. What happened when the machine became armed? Move the machine and sew a little then pause. Notice that although you have needle down selected, the needle stays up when you pause. Sew again then pause and disarm the machine. What happened? The needle only goes down, if you have it selected, when you disarm the machine not when you pause.

When you select needle down in either regulated stitching or constant speed, you need to wait for the needle to lift out of the fabric before moving off. When to use needle down will be covered later.

Get into the habit of glancing at your control panel every time you get ready to arm the machine to make sure the mode switch and the slider are set where you want them. This is especially important when you move from one side of the machine to the other.

And now some questions to help you remember the features of Equalizer.

1. When you power up, what does the beep mean? What does the machine always do at power up?
2. How do you arm the machine?
3. How do you take a single stitch?
4. What do the bars above the slider represent?
5. What is constant speed? Where do you set the mode switch to sew in constant speed?
6. How do you start with needle down? What happens when you arm the machine with the needle down?
7. What does a flashing red fail light accompanied by a beep mean when you are quilting?
8. When you pause, what happens after 8 seconds of no movement?

LESSON 2. USING REGULATED STITCHING - MINIMUM EFFORT METHOD

The instructions in this lesson are less detailed than in lesson 1 as it is assumed that you know how and when to tie off your threads and, of course, when and how to arm and disarm your machine. You should advance your practice piece as necessary. Please repeat the individual exercises if you feel you need more practice at any stage. Read each paragraph through before beginning to sew.

We recommend to practice the machine movement technique when you first get your Equalizer as it is important for you to move your machine correctly to get the best results. If you have been quilting with an unregulated machine for a long time, you are probably skilled at moving off fast and jerking quickly through points to stop that build up of little stitches. With the Equalizer, you don't need to do that anymore – in fact you shouldn't do that because it will result in long stitches as the sudden, fast change in speed will be too hard for the regulator to keep up with.

Thread your machine with one that you know works well – this is not the time to try out new threads. It should be of a contrasting color to the fabric of your practice piece, which should be already mounted.

Work at the front of your machine.

Start at the top left of your practice piece. Set the mode switch to regulated mode and the slider to the leftmost bar (about 6 SPI). Secure the thread ends and sew a wavy or undulating line across the full width of your quilt sandwich. Move the machine at a moderate speed. When you reach the right hand side, make a U-turn and echo the first line about half an inch below back to the left edge. Disarm your machine and move the slider to the next bar. Echo again across to the right side and back to the left. Pause there. Do not disarm your machine. Pause once more and move the slider to the next bar and continue sewing as before. Repeat this until you reach the rightmost bar. Disarm your machine.

You have now sewn with all the different sizes of regulated stitches that you might choose when quilting. Look at your lines of quilting. Are all your stitches even or do you have some longer stitches where you started off after a pause? If you see long stitches at that point, you were moving off too fast. When you start out, you need to accelerate slowly. The next exercise helps you practice this slow start.

Set your slider to the left again. Begin at the left hand side of your piece. This time sew a straight line for about 6 inches then pause. Continue sewing for another 6 inches and pause again. Continue sewing and pausing all the way across and back again to the left side. Now repeat the exercise using all the stitch lengths.

How did you do?

If you find that you are still getting a long stitch as you start, try using one hand to gently guide the machine. Use one hand, then the other and then just the fingertips of both hands to gently push the machine. This is quilting with the minimum of effort. Guide the machine gently – do not force it. Since you do not need to keep your finger hovering over the start/stop button, ready to press it quickly when you want to stop, you can position your hands anywhere that is comfortable.


Now do a medium sized meander over the rest of the exposed quilting area. Pause now and again and change the stitch length occasionally too. Vary the speed with which you move the machine. When you've filled the space, tie off your threads and study your stitches. Can you see where you paused and didn't change the stitch length? Can you see where you changed speed? If you can, you accelerated too fast. Which stitch length do you like the best?

Advance your piece.

Set your slider to the stitch length you prefer.

Now you are going to sew some designs with sharp changes in direction in order to learn the correct way to move the machine.

Sew a row of clamshells like this. They should be about 2 inches across and nicely rounded. As you come to each point, you should not hear a beep. If you do, you are moving incorrectly. You need to slow down slightly as you go through the change in direction. This is a natural movement – do not force the machine to change direction, guide it.



If you did not hear beeps at any point, well done! If you did, just repeat the line of clamshells, holding your machine gently using its momentum to change direction. If you still hear a beep at some points, don't worry, go on to the next exercise. This movement can take time to learn.

Now try some upside down clamshells.


If you are comfortable quilting feathers, try some next. Sew a couple of rows. Remember, your goal is not to hear a beep at any sharp change in direction.

Now you are going to sew some rows of leaves like this. Trace the design first with your finger if you are not familiar with this type of leaf vine. There are some spaces to make the design path clearer, you do not need to leave these gaps when you sew. Listen for the beeps.



Sewing this next holly leaf vine is a good test for your change of direction skills. If you don't hear a beep at any point – very well done!

Make the individual leaves about 3 or 4 inches long, then try making them smaller.



If you quilt with pantographs, go to the back of your machine and choose one with some sharp changes in direction to practice. You will use the control panel at the back so remember to look at it to make sure the mode switch and the slider are set where you want them to be and watch for the run light to come on when you arm the machine. You will also be using your laser light or stylus.

After you have sewn some of the pantograph, pause and change the stitch length. At the end of the pass, stop and look at your stitches to see which size you liked the best and how the different lengths affected the look of the pattern. Which looks the best? Did you hear beeps at some changes in direction?

LESSON 3. USING REGULATED STITCHING - MORE PRACTICING

Now that you have an understanding about how to move the machine correctly, this lesson will help you use the regulated stitching mode.

Go to the front of the machine and bring up the bobbin thread and secure the thread ends. Set your mode switch to regulated mode and the slider to the rightmost bar. Stitch in a straight line across your practice piece. Start off slowly and gradually move the machine faster until you see the fail light flash and hear a beep. Sometimes it is hard to hear the beep. Slow down and pause. Disarm your machine and look at your stitching line. What was that flash of the fail light and beep telling you?

This is another way that the machine helps you move it correctly – go too fast and the regulator cannot keep up, the stitches will begin to lengthen. When they become twice the length you have chosen, the beep will sound and the fail light will flash. The machine is telling you to slow down.

Start at the left hand side of your practice piece and stitch a row of clamshells as you did in the last lesson. You should hear no beeps at all. Did you hear any? If you did, look at your points – why did you hear a beep? Did you notice the fail light flash? If so, why did it do that?

Stitch a row of the upside down clamshells too. How did you do this time?

Next quilt some feathers, then a row of the rounded leaves and finally a row of the holly vine. Did get any long stitches? If you didn't have any at all – congratulations! If you are still getting long stitches, don't worry. Some more practice will help to eliminate them.

Set the slider to the leftmost bar and sew a small meander – make the stitched lines about half an inch apart. Pause after a little while and change the slider to the next bar then continue meandering. Continue moving the slider to the right and try the same pattern, until reaching the shortest stitch length.

Look at your quilting – which meandering looks the best? Notice how the shorter stitch lengths give smoother curves.

Try some even smaller stippling and compare how the stitch size affects the look of the quilting.

Experiment some more with the different stitch lengths to see which ones you like the best. Sew some rows of your favorite design either freehand or following a pantograph. Pause to change the stitch length. Try them all then decide which looks the best to you. This is a personal decision although it is always best to use a shorter stitch length for a smaller design, especially one with lots of curves.

Get your favorite straight guide, if you have one. One of the advantages of the Equalizer is being able to sew slowly and carefully, pausing whenever you need to when using guides or templates.

Set your slider to the stitch length you prefer. You are going to stitch a zigzag line across your practice piece. It is helpful to start with your needle down when using a guide as this allows you to place the guide next to the foot exactly where you want to start quilting.

Secure your thread ends then put your needle down. Place the guide next to the machine's foot. If you have not used a guide before, just hold it gently and don't press it hard against the foot or the extended base – it is just a guide to stop your machine from wandering away from the diagonal. Sew up as far as you can along the length of the guide stitching a diagonal line then pause. Now reposition the guide and sew down the next leg of the zigzag. Continue in this way across your piece. Notice how the needle does not go down when you pause. You have needle down selected, so when will the needle stop in the down position?

Now draw a medium sized triangle on your practice piece with a pencil. Use your guide to help you sew on your drawn lines.

Next draw a simple daisy type flower. Imagine this is an appliqué. You are going to sew next to your line very carefully. If you have a stitch in the ditch guide, use it to help you guide your machine. Remember, you can pause when necessary and move as slowly as you need to. There is no need to keep the machine moving all the time or have your finger ready to stop it – but you should be used to that by now.

If you do not have a stitch in the ditch guide, you can use a straight edge to help you sew curves. Hold it gently against your foot and reposition it as necessary when you sew. There is

no need to stop moving the machine every time you need to reposition it, just slide it gently to a new position to help the machine move in the direction that you want it to go.

Draw some different shapes to simulate appliqué and practice sewing around them. You could draw different leaves, a simple animal or a house for example.

Finally, if you have some circle templates or other shapes, sew around them. Notice how you can relax as you quilt and only need to pause, not disarm the machine, to reposition your hand. If you are good at moving off slowly after a pause, you will not be able to tell where you paused when you look at your finished shape.

LESSON 4. USING CONSTANT SPEED

What is constant speed mode? Do you remember from lesson 1?

It simply means that when you arm the machine, the motor will run at a constant speed. The stitch length will depend on how fast or how slowly you move the machine.

Power up your machine and do the warm up if you haven't already done so today.

Read through the whole lesson before beginning to quilt.

To set your machine in the constant speed mode, set the mode switch to its "up" position. The slider is used to change the speed. At its leftmost setting the machine will make one stitch every second. As you move the slider to the right, the speed increases until it reaches its maximum value, which can be adjusted to your preference.

Set your slider to the leftmost position, secure your thread ends. When you arm the machine this time it will start to sew straight away so be ready to move the machine. Since it will only take one stitch per second, you do not need to move off quickly. Move your machine slowly at first, then gradually increase the speed with which you move it to increase the stitch length. This setting is good for doing basting stitches, for example. Sew a line of long basting. Remember that you cannot pause and expect the machine to stop sewing in this mode, so if you want to pause to admire your stitches, you have to disarm the machine.

Did you notice how there was no drag on the thread? This is called No-Drag Slow Speed.

Now move the slider towards the maximum. The motor runs faster and faster until it reaches the maximum. Your maximum setting may be quite different to someone else's as the Equalizer has been customized to suit you.

This time before you arm your machine, set the needle down. You should be used to the machine not starting to sew until you move it by now, so to have it start immediately can be a surprise and you might not be ready to move off. If you start with the needle down, you have to wait for the needle to be lifted out of the fabric before moving the machine. That fraction of a second gives you time to think and be ready.

Try sewing a little, first starting with the needle up, then with the needle down. Do you like starting with the needle down?

Set the slider at the middle. Put the needle down then arm the machine and start to sew. As you go along, gradually increase the speed of the motor by adjusting the slider.

Now sew some designs with the slider set at different points so that you get to know your machine's speed range.

Tie off your threads and move the machine away from your practice piece.

LESSON 5. COMPARING REGULATED STITCHING TO CONSTANT SPEED

This final lesson will help you to decide how you will use all the features of Equalizer.

Every quilter has their own style - some will use the stitch regulator all the time, others may find that they like to quilt certain designs very fast and so constant speed will be best for those. At the other extreme, some quilters may find that they only use the stitch regulator when they are doing careful work where they need control when moving the machine slowly. The way you choose to use the Equalizer is entirely up to you. Its many modes of operation allow you the freedom to quilt without stress.

Prepare your machine to sew. If you have not done the warm up today, go through that routine first.

Remember to glance at your control panel before you start quilting to make sure the mode switch and the slider are set where you want them to be and to check whether it is armed. This is especially important when you move from one side of the machine to the other.

Before you begin sewing, take a pencil and mark lines about 12 inches apart and about 6 inches long across the width of your practice piece like this:



Secure your threads at the left hand edge of your practice piece. Set your machine in regulated stitching mode at a stitch length you like. You will sew a straight line across your quilt. As you sew across the piece, pause at each line. Continue sewing and pausing all the way across. Tie off your threads and go back to the left ready to start again.

This time set the machine to constant speed, choosing a speed higher than 10, and do the same thing - stopping at each line. (Remember that starting with the needle down gives you a little time after you arm the machine in constant speed before you have to move off as you have to wait for the machine to lift the needle out of the fabric)

Tie off your threads and look at the three lines of stitching. Can you see by looking at the stitches where you paused when in regulated stitching mode? How about when in constant speed?

If you are already very good at moving off gradually, you should not be able to tell where you paused in regulated stitching mode. This is a big advantage when you are working on a quilt and need to keep pausing to re-adjust a guide or move yourself to a new position in front of the machine. When your bobbin thread runs out, the evenness of the regulated stitches make the break unnoticeable. Stops and starts become less visible.

This time sew a line of loops like this at a speed you would normally use when quilting.




Sew two rows, one in constant speed, one in regulated stitching mode, No need to keep pausing this time.

When you have completed the two rows, look at your stitches. How do the two rows compare? Which mode was the best for you? Did you move the machine too fast for the stitch regulator? Were your stitches even when using the regulated stitching but varied in size when in constant speed?

There are no right or wrong answers to these questions - they are simply helping you understand how you will ultimately use the different features of the Equalizer.

Now sew two rows of this zigzag in the same way. Use a guide to keep the lines straight.



How did you like sewing this in each mode? Was it easier when using the regulated stitches? Look at your stitches - which row looks the best and has even stitches? Notice how you had to keep pressing the stop/start button every time you changed direction when using constant speed.

Repeat the exercise again but this time sew one of your favorite pantographs. If you do not usually sew pantograph patterns, do two rows of feathers.

SUMMARY

These four exercises are enough to give you some idea of how you will use the Equalizer when working on a quilt.

You should now have a basic understanding of how it will work for you and which mode to choose for each type of quilting. However, your choice may change from quilt to quilt and from day to day and will certainly change as your experience and skill in using the Equalizer grow.

These lessons have given you a good start in using your Equalizer but don't base your future use of the different modes entirely on this limited practice. Right now you might prefer constant

speed. However, you should use the regulated stitching mode all the time for a while. This will train you in moving the machine correctly for the best results. Sometimes you may move the machine just too fast for the regulator and need to switch to constant speed. But by first having tried to use regulated stitching, you will be sure that your decision to use constant speed for a particular design or type of quilting is based on good experience.

Eventually you will realize that you are quilting without worrying about keeping the machine moving or having to press the start/stop button quickly. You will be able to place your hands anywhere that is comfortable and use minimum of effort to guide the machine. You will be concentrating on what you are quilting rather than how you are quilting. You will be in charge of your machine and using every feature to its best advantage.

A FINAL TEST OF YOUR KNOWLEDGE

If you can answer all these questions without referring back to the relevant sections or any of the lessons, congratulations - you have learned a lot!

1. What will your machine always do when you power up?
2. What does the no-drag slow stitching mode mean?
3. When in regulated stitching mode, what does the machine do after 8 seconds of no movement?
4. What does it mean when the fail light flashes and you hear a beep at the same time in regulated mode?
5. When should you use constant speed rather than regulated stitching?
6. What should you do each day before starting to quilt?
7. Why do you need to keep the two tracks, that the sensor wheels ride on, clean?
8. What should you do every time just before you press the start/stop button?

HELP!

My machine started beeping very fast after powering up. What does this mean?

This indicates that one of the switches is shorted. Turn off the machine and call for service.

My bobbin thread is lying on the backing fabric – not sinking into the quilt sandwich – and I can see dots of the top thread. Should I run the adjustment procedure?

No, this is a tension problem, not an Equalizer problem. First make sure that your top thread is threaded correctly. If it is, then thoroughly clean your bobbin case and bobbin assembly. If the tension still looks bad, either tighten the top tension or loosen the bobbin tension. You may need to do both. Only trial and error will show you the right thing to do, but make a note of what you do so that you can keep a record for future reference.

I am getting a long stitch when I start off and sometimes when I make points. How can I stop that?

You are moving the machine incorrectly. Remember, use minimum effort to guide the machine – do not move suddenly – relax.

I am getting a long stitch every now and then when I am quilting and it's not at the beginning or at a point - what's wrong?

Look closely at the long stitch - do you see a needle hole through the quilt in the middle of the stitch? If so, then your machine has skipped a stitch - it has not picked up the bobbin thread. This could happen for a variety of reasons: the hopping foot is too high, the take up roller is set too high, or your quilt is stretched too tightly. It could also be because the fabric has a finish of heavy printing, which is slowing the needle slightly as it passes through. Too high tension setting, small burrs that hold back the thread also may cause skipped stitches. If the long stitches appear consistently as you move the machine away from you, when working at the front of the machine, then you should check your timing - the hook may need to be moved closer to the needle.

If you cannot determine whether these long stitches are skipped stitches, watch as you are quilting to see if the machine is skipping, i.e. does not make a stitch when it is supposed to. If it is the case, you should check the cleanliness of your tracks and your sensor wheels. Contact your dealer.

ADJUSTMENT PROCEDURE EQUALIZER REV 1.X

The REV 1.x revisions of the EQUALIZER software provide adjustment means to set the needle speed, the needle positioner's up and down positions and the constant speed range. The SLIDER on the back of the machine is used to select the adjustment modes. **NOTE that the front slider is disabled in adjustment mode.**



REAR SLIDER POSITION

ADJUSTMENT MODE

first bar	needle positioning speed (auto adjustment)
third bar	regulated speed
fifth bar	needle up/down positions
eighth bar	maximum constant speed



The MODE SELECTOR SWITCH is used to select between increasing (switch up) and decreasing (switch down) the settings

To enter the adjustment mode, hold the REAR NEEDLE POSITION BUTTON down while powering up the unit. The button should be held down until the machine beeps once.

You can also enter the adjustment mode, WITH THE FACTORY DEFAULT SETTINGS RELOADED, by holding the NEEDLE POSITION and START buttons down simultaneously while powering up the machine.

The green light will flash to indicate that you are in the adjustment mode.

It is recommended to perform the adjustment with a threaded machine, over a quilt, or practice piece. The machine should be moved after each stitch to avoid thread pile-up at the same spot.

A. NEEDLE POSITIONING SPEED AUTO ADJUSTMENT

In this mode the needle speed for the needle positioner is adjusted by an automatic process.

Note that the needle positioning speed adjustment will affect ALL of the other settings, so it should be performed first.

1. Move the slider knob to the first bar.
2. Push the RED BUTTON. Three short beeps will indicate that the auto adjustment is about to start. During the adjustment several stitches will be made. Make sure that you move the machine between stitches to avoid pile-up at the same spot. The needle positioning speed will be automatically adjusted until the take-up lever reaches the optimal "up" position. You will hear a beep after each stitch where the take-up lever is at this position. If three consecutive stitches produce the same, correct position, the auto adjustment is finished, indicated by three short beeps.



NOTE: If the proper take-up lever position is not reached after taking 20 stitches, the process stops with one long beep. Possible causes of this may include intermittent drag (tight spot) in the mechanism, trapped thread, improper tension setting, etc. After eliminating the problem, you need to repeat the auto adjustment until proper completion.

B. REGULATED STITCHING SPEED

The REGULATED STITCHING SPEED directly affects the quality of the stitch regulation. If you can "outrun" the machine, in other words, the stitches get longer when you move the machine faster, the REGULATED STITCHING SPEED is not high enough. On the other hand, if the stitches are shorter than the selected length, because double stitching occurs, the REGULATED STITCHING SPEED is too high. Too high speed can also cause motor overheating.

The AUTO ADJUSTMENT sets the REGULATED STITCHING SPEED to a level that is optimal for a machine with average mechanical drag. However, some machines may run slower than the average, usually during their first month(s) after coming out of the manufacturer, or because of minor misalignments in the mechanism. **In case of a "tighter" machine, we strongly suggest to investigate the causes of the tightness first. Only if the investigation does not reveal mechanical problems as the cause of tightness do we recommend adjusting the REGULATED STITCHING SPEED.**

While all of the other adjustments are "What You See Is What You Get", the REGULATED STITCHING SPEED setting requires testing outside the adjustment mode: After changing the speed, return to the normal operating mode by turning the power off and on again. Test the quality of the stitch regulation by moving the arm with your slowest and fastest speed and decide whether further adjustments are necessary. If yes, return to the adjustment mode and make the changes.

In order to help you in memorizing the settings, and to make the phone assistance from a service representative easier, the actual REGULATED STITCHING SPEED correction is reported by AUDIBLE INDICATION, a series of short and long beeps every time you push the RED BUTTON. The relationship between the beeps and correction steps is shown on the table below. The short beeps are marked by "•", the long ones by "—".

AUDIBLE INDICATION	CORRECTION	AUDIBLE INDICATION	CORRECTION
• • •	0	• • —	+1
• — •	+2	• — —	+3
— • •	+4	— • —	+5
— — •	+6	— — —	+7

The optimum setting of the REGULATED STITCHING SPEED will be just high enough to provide accurate stitch length, but not too high to cause motor overheating or double stitching. Always start with the speed set by the AUTO ADJUSTMENT, and gradually increase it until acceptable regulation is reached. **NOTE THAT SETTINGS ABOVE +3 ARE RESERVED FOR 50HZ OPERATION.**

To change the REGULATED STITCHING SPEED, follow the procedure below:

1. Based on the regulation quality test, decide if the speed needs to be increased or decreased.
2. Set the mode switch up if the speed needs to be increased, set it down if decreasing is necessary.
3. With the slider knob at the third bar, push and hold down the RED BUTTON. A series of short and long beeps will report the actual speed correction setting.
4. While still holding the RED BUTTON down, hit the BLACK BUTTON. A beep will indicate that the speed was increased/decreased and the new value was stored in the computer's memory. A missing beep indicates that a high/low limit was reached.
5. Release the RED BUTTON and repeat the procedure from Step 3, changing the speed by one or two steps at a time.
6. Set the machine in normal operating mode and test the results of the adjustment.
7. Repeat the procedure from Step 1, if necessary.



C. NEEDLE UP/DOWN POSITION ADJUSTMENTS

The needle position sensor's timing is set at the time of the installation, there is no need to re-time the sensor. It is recommended, however, to check the proper timing before the needle position adjustment takes place.

To check the sensor timing:

1. While watching the red FAIL light, turn the handwheel **very slowly** to the forward direction (counter-clockwise, if viewed from the rear) until the light comes on. If the light just flashes, turn the handwheel backward until the light is on again. With fine adjustments of the handwheel the red light can be constantly turned on.
2. If the red light stays on when the needle is at its lowest position, the timing is correct, you can proceed to the UP/DOWN POSITION ADJUSTMENT.
3. If the red light is turned on when the needle is not at the desired position, please call the manufacturer for assistance.

The AUTO ADJUSTMENT sets the NEEDLE UP/DOWN POSITIONS to levels that are optimal for a machine with average mechanical drag. However, just like in case of the REGULATED STITCH SPEED, on tighter machines these positions may be slightly off after the AUTO ADJUSTMENT. **In case of a tighter machine, we strongly suggest to investigate the causes of the tightness first. Only if the investigation does not reveal mechanical problems as the cause of tightness do we recommend to adjust the NEEDLE UP/DOWN POSITIONS.**

The NEEDLE UP POSITION should be readjusted when after pulling it up with the needle position button

- the take-up lever is not high enough to release the thread from the hook, in which case the needle up position needs a forward adjustment, or
- the machine over-rotates, i.e. the needle passes its top position and gets too close to the fabric again, when a backward adjustment is needed.

The NEEDLE DOWN POSITION should be readjusted when after moving it down with the needle position button

- the needle is not stopping low enough to keep the arm securely at the given position, in which case the needle down position needs a forward adjustment, or
- the machine over-rotates, i.e. the needle passes its bottom position and starts coming out of the fabric, when a backward adjustment is needed.

To adjust the NEEDLE UP/DOWN POSITIONS:

1. Move the slider knob to the fifth bar.
2. Push and hold down the RED BUTTON. A needle positioning step (up or down) will be made.



To differentiate between the "up" and "down" positions a beep will sound when the needle is supposed to be at the "up" position.

3. Check the up or down position of the needle.
4. If the up(down) position is correct, release the RED BUTTON, and go to Step 1 to check the other position.
5. If the up(down) position is not acceptable, while still holding the RED BUTTON down, test whether forward or backward adjustment is necessary:
 - Turn the handwheel slowly forward (counter-clockwise, if viewed from the rear)
 - If the take-up lever and the tip of the needle are going TOWARD the right positions, FORWARD ADJUSTMENT is necessary, so set the mode switch up.
 - If the take-up lever and the tip of the needle are going AWAY from the right positions, BACKWARD ADJUSTMENT is necessary, so set the mode switch down.
6. While still holding the RED BUTTON down, hit the BLACK BUTTON. A beep will indicate that the new position was stored in the computer's memory.
7. Release the RED BUTTON. To check the setting you have just adjusted, press and release the RED BUTTON, then press the RED BUTTON again and hold it down. Go back to step 5.
8. If the setting is correct for the position you have just checked, release the RED BUTTON then press the RED BUTTON again and hold it down. You are now checking the opposite position. Repeat the procedure until the desired needle positions are reached.

D. MAXIMUM CONSTANT SPEED ADJUSTMENT

1. With the slider knob at the eighth bar, push and hold down the RED BUTTON. The motor will start running continuously with the fastest constant speed.

Note that the RED BUTTON should be held down continuously during the whole procedure. Make sure you move the machine to avoid thread pile-up.



2. If the maximum speed needs adjustment, while still holding the RED BUTTON down, set the mode switch up if the speed needs to be increased, set it down if decreasing is necessary.
3. While still holding the RED BUTTON down, hit the BLACK BUTTON. A beep will indicate that the speed was increased/decreased. Repeat the procedure from Step 2 until the desired maximum speed is reached.
4. Release the RED BUTTON to save the adjusted maximum speed in the computer's memory.

After the adjustments are made the power should be turned off and on again to start the unit in normal operating mode.